Easy Equipment

66 Jersey Street, Manchester, M4 6JW, UK | VAT: GB606624256 sales@easyequipment.com / 0333 3443 979

Vogue Utensil Wash Only Sign L956

230 x 90mm

Code: L956

View Product



This sink for utensil wash only



£5.25

£2.99 / exc vat

£3.59 / inc vat

Select Shipping Method

- Next Working Day delivery

Notes :

- Please check door entry sizes before ordering.
- Delivery is made to kerbside only.
- Drivers do not unpack or position goods.
- A 25% restocking charge will apply for all returned goods.

This essential catering sign displays a clear message to staff, to warn that only utensils should be washed in a specific sink to help reduce the spread of germs and bacteria in kitchens and food prep areas.

Highly visible and clear guidance is crucial within the catering industry to help avoid mistakes which can result in serious health risks to your customers.

- · Self adhesive vinyl
- · Highly visible
- Easy to clean
- · Essential food safety sign
- · Helps prevent the spread of germs
- 230(H) x 90(W)mm

EasyEquipment make every reasonable effort to ensure the accuracy and validity of the information provided on its web and PDF pages.

However, as product information, technical details and prices are continually changing, EasyEquipment reserve the right to change at any time without notice, information contained on its website and make no warranties or representations as to its accuracy. EasyEquipment © 2024, All rights reserved. E&OE. Page printed on "03-05-2024" at "02:25:03"