

CLEANING AND CARE INSTRUCTIONS

Products Include

- Camtrays®
- Camlites® Trays
- Camtread® Trays
- Treadlite™ Trays
- Non-Skid Versa Camtrays®
- Versa Camcovers® (plate cover)

Washing Instructions

All Cambro fiberglass products need to be washed thoroughly before their initial use.

All Cambro fiberglass products are commercial dishwasher safe.

For occasional hand washing or to remove stains follow the instructions below:

For Occasional Hand Washing

1. Use dish soap with warm water.
2. Rub the surface using a non-scratch scouring pad (Scotch-Brite), plastic or bristle brush.
3. Do **NOT** use abrasives (such as Comet, Ajax, etc., or metal scouring pads).
4. Rinse thoroughly with clean water.
5. Always make sure that the trays are dry before stacking.

To Remove Stubborn Stains

General Rule: The longer stain stays on, the harder it is to remove.

1. Apply a small amount of liquid cleanser to the stained area of the tray.
Cleanser options:
 - Lime Away
 - Soft Scrub Liquid Gel with Bleach
 - Soft Scrub Total All Purpose Bath and Kitchen Cleanser
2. Rub the affected area using a non-scratch scouring pad (Scotch-Brite), plastic or bristle brush.
3. Once the stain is removed, thoroughly rinse the tray with clean water.
4. Always make sure that the trays are dry before stacking.

Note: Trays that cannot be washed with bleach but are stained can also be left in direct ultraviolet/sunlight and the stain will fade with time.

Disclaimer

Please note that foods such as mustard, coffee, dark soft drinks, berries, fruit juice, green tea, tomato juice, tomato paste, curry and chili paste contain natural pigments that may stain trays if left on the surface for extended periods of time. To prevent staining, wash trays within one hour of use.

The Cambro logo consists of the word "CAMBRO" in a bold, red, sans-serif font. A small registered trademark symbol (®) is located at the bottom right of the word.