

Care In Use Polycarbonate Plastic

To ensure the long life of Polycarbonate plastic proper handling is essential.

USES

Dishwasher Safe, providing appropriate detergent is used for cleaning and aftercare.

Recommended cleaning in warm water with a soft cloth using an alkali free detergent.

Temperature resistance, maintains rigidity up to 120°C and toughness down to -20°C.

High impact resistance and shatter resistant.

Light weight.

Secure locking and stackable system.

Clear high quality plastic for visual properties.

MISUSES

Do not clean with sodium hypochlorite (bleach) or other alkali cleaners dulling and clouding of plastic may occur.

Do not use abrasives cleaners or scratch pads when cleaning.

Not suitable for conventional ovens, under browning elements or on stove tops.

Do not use in microwave.



Food Safe Product Regulations for plastic materials in contact with food. Commission Directive 2002/72/EC EC Regulation No. 1935/2004



Recycling type 7: Polycarbonate "other" (means it can contain bisphenol A, a plasticizer is leached out by heating in a microwave).

Churchill Plc (UK) Marlborough Pottery, Stoke-on-Trent, ST6 5NZ, England T: +44(0)1782 524358 E: diningout@churchillchina.plc.uk www.churchillchina.com