



Machine	Explode	Code	Description
Waring Panini Grill Single	1	æ	PIVOT BRACKET SCREW SET (1 SMALL & 1 LARGE)
Waring Panini Grill Single	2	A	PRIVOT BRACKET
Waring Panini Grill Single	3	æ	SET SCREW 2 REQ.'D
Waring Panini Grill Single	4	2	CONTROL KNOB
Waring Panini Grill Single	5	2	DRIP TRAY
Waring Panini Grill Single	6	2	FOOT 4 REQ.'D
Waring Panini Grill Single	7	2	FOOT SCREW 4 REQ.'D
Waring Panini Grill Single	8	A	ON/OFF SWITCH
Waring Panini Grill Single	9	A	INDICATOR LIGHT
Waring Panini Grill Single	10	AD216	THERMOSTAT
Waring Panini Grill Single	11	a	SCREW/ THERMOSTAT 2 REQ.'D
Waring Panini Grill Single	12	A	COVER
Waring Panini Grill Single	13	A	WASHER 4 REQ.'D
Waring Panini Grill Single	14	A	SCREW 4 REQ.'D
Waring Panini Grill Single	15	2	BOLT/ HEX HEAD
Waring Panini Grill Single	16	2	WASHER
Waring Panini Grill Single	17	2	INSULATION PLATE/ TOP
Waring Panini Grill Single	18	2	INSULATION/ TOP
Waring Panini Grill Single	19	x	ELEMENT PLATE/ TOP
Waring Panini Grill Single	20	x	BOLT/ HEX HEAD 4 REQ.'D
Waring Panini Grill Single	21	æ	WASHER/ SPRING 4 REQ.D
Waring Panini Grill Single	22	*	WASHER 4 REQ.'D
Waring Panini Grill Single	23	2	FIBER SLEEVE 2 REQ.'D
Waring Panini Grill Single	24	æ	PLASTIC SLEEVE 2 REQ.'D
Waring Panini Grill Single	25	*	SCREW 2 REQ.'D
Waring Panini Grill Single	26	*	WASHER 2 REQ.'D
Waring Panini Grill Single	27	æ	ELEMENT / TOP
Waring Panini Grill Single	28	*	TOP GRILL PLATE/ RIBBED
Waring Panini Grill Single	29	*	SCREW
Waring Panini Grill Single	30	æ	TENSION SCREW
Waring Panini Grill Single	31	æ	TENSION BRACKET
Waring Panini Grill Single	32	*	SCREW 4 REQ.'D
Waring Panini Grill Single	33	*	WASHER /SPRING 4 REQ.'D
Waring Panini Grill Single	34	*	BRACKET/ LARGE HANDLE 2 REQ.'D
Waring Panini Grill Single	35	*	BOTTOM GRILL PLATE/ RIBBED
Waring Panini Grill Single	36	*	BRACKET/ THERMOSTAT
Waring Panini Grill Single	37	æ	WASHER 2 REQ.'D
Waring Panini Grill Single	38	*	SCREW 2 REQ.'D
Waring Panini Grill Single	39	*	FIBER SLEEVE 2 REQ.'D
Waring Panini Grill Single	40	2	PLASTIC SLEEVE 2 REQ.'D
Waring Panini Grill Single	41	2	SCREW 2 REQ.'D
Waring Panini Grill Single	42	*	WASHER 2 REQ.'D
Waring Panini Grill Single	43	*	ELEMENT/ BOTTOM
Waring Panini Grill Single	44	*	ELEMENT PLATE/ BOTTOM
Waring Panini Grill Single	45	2	WASHER 4 REQ.'D
Waring Panini Grill Single	46	2	WASHER/ SPRING 4 REQ.'D
Waring Panini Grill Single	47	2	BOLT/ HEX HEAD 4 REQ.'D

Exploded diagram and spare parts li	st
-------------------------------------	----

ist CE230

Exploded diagram and spare parts list CF230				
48	2	NUT		
49	2	INSULATION/ BOTTOM		
50	2	INSULATION PLATE/ BOTTOM		
51	2	WASHER		
52	A	NUT		
53	A	SCREW 2 REQ.'D		
54	A	WASHER 2 REQ.'D		
55	A	REAR COVER WITH TENSION COVER		
56	A	REAR COVER PLATE WITH TENSION HOLE		
57	A	LARGE HANDLE		
58	a	SCREW / HEX HEAD 2 REQ.'D		
59	a	NUT 2 REQ.'D/ HANDLE		
60	A	THERMAL CUT OFF		
61	A	WASHER 2 REQ.'D		
62	a	NUT 2 REQ.'D		
63	A	WASHER 4 REQ.'D		
64	A	WASHER/ SPRING 4 REQ.'D		
65	A	BOLT 4 REQ.'D		
66	WA105	WIRE TIE 7 REQ.'D		
67	A	LEAD/ RED LONG		
68	A	LEAD/ READ LONG & WHITE JOINED		
69	a	LEAD/ BLACK LONG & WHITE JOINDED		
70	a	LEAD/ RED SHORT		
71	2	BOTTOM HOUSING PLATE		
72	2	SCREW 4 REQ.'D		
032000	2	CLEANING BRUSH		
029824	2	5/32 SHORT ARM HEX KEY		
503319	a	BASE UNIT ASSEMBLY		
	48 49 50 51 52 53 54 55 56 57 58 59 60 61 62 63 64 65 66 67 68 69 70 71 72 032000	48 2 49 2 50 2 51 2 52 2 53 2 54 2 55 2 56 2 57 2 58 2 60 2 61 2 62 2 63 2 64 2 65 2 66 WA105 67 2 68 2 69 2 70 2 71 2 032000 2 029824 2		