
The plastic laminate surface and ABS edge should be cleaned using a non-abrasive solution.
DO NOT USE POLISH.

The table frame and legs can be cleaned by simply wiping with a damp cloth.

Sizemark as defined by EN1729-1:2006
Furniture - Chairs and tables for educational institutions



Fit the legs to frame by tightening the two button head screws located in each corner of the frame using the Allen key provided. You must ensure that the legs are pushed in fully before securing the button head screws very tightly. Please note that the screws should be fully tightened so that the head on the screw butts up tightly to the aluminium corner connector.